
13245 INSTALLATION INSTRUCTIONS

CURT



YEARS: 2008-CURRENT **MAKE: JEEP MODEL: LIBERTY STYLE: SUV** WARNING: NEVER EXCEED YOUR VEHICLE MANUFACTURER'S RECOMMENDED TOWING CAPACITY WEIGHT CARRYING: WEIGHT DISTRIBUTION: **TRAILER WEIGHT:** 7,500 LBS. TRAILER WEIGHT: 5,000 LBS. **TONGUE WEIGHT:** 500 LBS. **TONGUE WEIGHT:** 750 LBS. **INSTALLATION TIME:** 20 MIN. **INSTALLATION TIPS:** VEHICLE PHOTO: 1. BEFORE YOU BEGIN INSTALLATION, READ ALL THE INSTALL TIME LISTED IS FOR PROFESSIONAL INSTRUCTIONS THOROUGHLY. INSTALLERS. IF YOU ARE HESITANT TO UNDERTAKE 2. TO EASE INSTALLATION, 2 PEOPLE MAY BE THIS TASK ON YOUR OWN, CONTACT AN AUTHORIZED REOUIRED. CURT INSTALLER FOR ADDITIONAL ASSISTANCE. CURT MFG 3. USING PROPER TOOLS WILL GREATLY IMPROVE THE OUALITY OF THE INSTALL AND REDUCE THE TIME REQUIRED. **INSTALLATION REQUIRES:** 4. NEED HELP OR HAVE SOME QUESTIONS? CALL TECHNICAL SUPPORT AT 800.798.0813 18mm 19mm LEVEL OF DIFFICULTY: EASY TORQUE EASY MODERATE CHALLENGING RATCHET SOCKET **WRENCH** WELDNUT CLEANING MAY **REPRESENTATIVE PHOTO BE REQUIRED** HITCH ILLUSTRATION: SAFETY NO DRILLING REQUIRED GLASSES MAKE SURE YOUR HITCH MATCHES

PERIODICALLY CHECK THIS RECEIVER HITCH TO ENSURE ALL FASTENERS ARE TIGHT AND ALL STRUCTURAL COMPONENTS ARE SOUND CURT Manufacturing LLC. warrants this product to be free of defects in material and/or workmanship at the time of retail purchase by the original purchaser. If the product is found to be defective, Curt Manufacturing LLC. may repair or replace the product at their option, when the product is returned, prepaid, with proof of purchase. Alteration to, misuse of, or improper installation of this product voids the warranty. Curt Manufacturing LLC.'s liability is limited to repair or replacement of products found to be defective, and specifically excludes liability for incidental or consequential loss or damage.

For more information log onto www.curtmfg.com, & for helpful towing tips log onto www.hitchinfo.com

INSTALLATION WALKTHROUGH:

Parts List		
ITEM QTY		
1 6		
2 6		

For more information log onto <u>www.curtmfg.com</u>, & for helpful towing tips log onto <u>www.hitchinfo.com</u>

Remove bolt from driver's side vehicle support bracket and return to vehicle owner.





+

Raise hitch into position.





INSTALLATION WALKTHROUGH:

Position hitch over frame and support bracket (driver side) and loosely install the supplied fasteners as shown.





Torque all 12mm fasteners to 79 lb-ft.



For more information log onto www.curtmfg.com, & for helpful towing tips log onto www.hitchinfo.com

Install is now complete.

┍╼






13245

JEEP LIBERTY

7/13/2012



- 1) Remove bolt from driver's side vehicle support bracket and return to vehicle owner.
- 2) Raise hitch into position.
- Position hitch over frame and support bracket (driver side) and loosely install the supplied fasteners as shown.
- 4) Torque all 12mm fasteners to 79 lb-ft.

PERIODICALLY CHECK THIS RECEIVER HITCH TO ENSURE THAT ALL FASTENERS ARE TIGHT AND THAT ALL STRUCTURAL COMPONENTS ARE SOUND.

Curt Manufacturing Inc., warrants this product to be free of defects in material and/or workmanship at the time of retail purchase by the original purchaser. If the product is found to be defective, Curt Manufacturing Inc., may repair or replace the product, at their option, when the product is returned, prepaid, with proof of purchase. Alteration to, misuse of, or improper installation of this product voids the warranty. Curt Manufacturing Inc.'s liability is limited to repair or replacement of products found to be defective, and specifically excludes liability for incidental or consequential loss or damage.