


# 4RUNNER - OE EDITION

## Crossbars

### Users Manual



Model year: **2010**

Maximum Load Capacity: **60 kg (132 lbs) Total, evenly distributed**


 Product Weight: **1.5 kg (3.3 lbs)**

## SAFETY NOTES:


- Never exceed the manufacturer's roof rack load limit of 132 lbs (60 kg). Please consult the owners manual for additional information on cargo carrying.
- Confirm tightness every 600 miles (1,000 km). When driving long distances, on rough roads, or at high speed, periodically check that the load is secure and that the crossbars are securely tightened.
- Carrying a load may change the driving behavior of the vehicle. Ensure that the load is evenly distributed between the two crossbars and that it is as low as possible.
- When attaching accessories (bike racks, ski racks, cargo boxes, etc) space the crossbars as described in this manual (approx. 700 mm between crossbars).
- Ensure that the crossbars are fully clamped to the side rail with no gaps.

## Crossbar Location

1



2



3

